



W.M. PLASTICS

Cure Out Powder

Solidify excess ink so it can be easily handled and thrown away.

Mixing Instructions:

- Add 20% by volume to ink
- Add 4 oz water per gallon
- Stir until mix (doesn't have to be a smooth mix)
- Let sit for 24 hours in a safe place
- Ink will steam after about 1 hour

Technical

<i>Substrates</i>	n/a
<i>Bleed Resistance</i>	n/a
<i>Opacity</i>	n/a
<i>Mesh</i>	n/a
<i>Screen Tension</i>	n/a
<i>Stencil</i>	n/a
<i>Squeegee Type</i>	n/a
<i>Squeegee Blade</i>	n/a
<i>Squeegee Angle</i>	n/a
<i>Squeegee Speed</i>	n/a
<i>Flashing</i>	n/a
<i>Gel Temp</i>	n/a
<i>Cure Temp</i>	n/a
<i>Extender</i>	n/a
<i>Caution</i>	Will react with water
<i>Storage</i>	Dry Area
<i>Wash-up</i>	Any Plastisol Screen wash or Mineral Sprits
<i>MSDS</i>	Sheet Number: 1